

Steckerbelegungen Sony PCGA-MDN1

J1 Flat ribbon connector, 16 pin	
Contact number	Assignment
1	
2	
3	
4	Audio GND
5	
6	Audio Output R
7	Audio GND
8	Audio Output L
9	
10	GND
11	USB D+
12	USB D-
13	GND
14	
15	VCC
16	VCC

J2 Vaio Interface connector, 42 pin			
Contact number	Assignment	Contact number	Assignment
A1	NC	B1	(connected to J2.B2)
A2	NC	B2	(connected to J2.B1)
A3	GND	B3	GND
A4	Address	B4	NC
A5	Address	B5	NC
A6	Address	B6	NC
A7	Address	B7	NC
A8	NC	B8	NC
A9	NC	B9	NC
A10	GND	B10	NC
A11	USB D+	B11	NC
A12	USB D-	B12	NC
A13	GND	B13	NC
A14	(connected to J1.9)	B14	NC
A15	Audio Output L	B15	NC
A16	Audio GND	B16	NC
A17	Audio Output R	B17	Audio GND
A18	(connected to J1.5)	B18	NC
A19	GND	B19	GND
A20	GND	B20	GND
A21	VCC	B21	VCC